


適用範圍：
手動液壓附爪起道機



編碼	品名	數量	品號
1	本體	1	DERVE011-A01
2	主軸	1	DERVE011-A07
3	上螺帽	1	DERVE011-A08
4	O型環	1	XBG055-NOK
5	背托環	1	XGG055
6	O型環	1	XBFO48-NOK
7	背托環	1	XGFP048
8	防塵罩	1	XDSD-48
9	銅華司	2	XWCI3-8-TT
10	CAP螺柱	2	XNCAPM08-40
11	銅襯	1	DERVE011-A19
12	墊塊	1	XKA-SRC-10
13	C型扣環	1	XAS-35
14	扁彈簧組	1	XFP23A-248
15	爪	1	DERVE011-A04
16	提把組	1	DERVE011-A-A2
17	油泵座組	1	SLJM10-A-A1
18	CAP螺柱	2	XNCAPM08-20
19	螺柱	1	XNSETM06-20
20	接桿	1	DERVE011-A10
21	背托環	2	XGFP010
22	O型環	2	XBFO10-NOK
23	螺柱	1	XNCAPM08-25
24	螺柱	1	XNBHM08-30


*修理包


適用型號系列:SLJM-10
SLJM10-A-A1

適用範圍：
手動液壓附爪起道機

編碼	品名	數量	品號
1	油泵座	1	DERVE011-A02
2	CAP螺栓	2	XNCAPM06-18
3	CAP螺栓	2	XNCAPM06-20
4	油箱	1	DERVE011-A05
5	油袋	1	DERVE011-A06
6	過濾器組	1	SP392-B09
7	逆止閥組	1	DERVE011-A-A5
8	安全閥組	1	SP392-B03
9	SET螺栓	2	XNSETM06-6
10	鋼珠	2	XM3/16
11	出口閥	1	DERVE011-A20
12	銅螺栓	1	STH-B26
13	塞頭	2	XN1/4PT
14	彈簧	1	XF0.3-D7-D4-5L-4T
15	半圓頭螺栓	1	XNBHM04-06-SUS
16	O型環	1	XBAS109
17	洩壓閥組	1	SP392-B06
18	C形扣環	6	XAS010
19	插銷-3	1	DERVE011-A13
20	O型環	1	XBPO18-NOK
21	背托環	1	XGPO18
22	防塵環	1	XDDSI018
23	油泵軸	1	DERVE011-A09
24	接板板	2	DERVE011-A14
25	插銷-2	1	DERVE011-A12
26	插銷-1	1	DERVE011-A11
27	接板	1	DERVE011-A03
28	華司	1	DERVE011-A25
29	防護板	1	DERVE011-A24
30	鋼珠	1	XM1/4


*修理包





Item	Description	Q'ty	Part No.
1	body	1	DERVE011-A01
2	plunger	1	DERVE011-A07
3	stop ring	1	DERVE011-A08
4	O-ring	1	XBG055-NOK
5	back-up ring	1	XGG055
6	O-ring	1	XBPO48-NOK
7	back-up ring	1	XGP048
8	dust ring	1	XDSD-48
9	cu washer	2	XWC13-8-1T
10	bolt	2	XNCAPM08-40
11	copper liner	1	DERVE011-A19
12	saddle	1	XKA-SRC-10
13	C type ring	1	XAS-35
14	spring assembly	1	XFP23A-248
15	toe	1	DERVE011-A04
16	handle	1	DERVE011-A-A2
17	pump assembly	1	DERVE011-A-A1
18	bolt	2	XNCAPM08-20
19	bolt	1	XNSETM06-20
20	plug	1	DERVE011-A10
21	back-up ring	2	XGP010
22	O-ring	2	XBPO10-NOK
23	bolt	1	XNCAPM08-25
24	bolt	1	XNBHM08-30

* repair kit



Item	Description	Q'ty	Part No.
1	pump assembly	1	DERVE011-A02
2	bolt	2	XNCAPM06-18
3	bolt	2	XNCAPM06-20
4	oil tank	1	DERVE011-A05
5	oil bag	1	DERVE011-A06
6	filter	1	SP392-B09
7	reflux against assembly	1	DERVE011-A-A5
8	safety valve	1	SP392-B03
9	bolt	2	XNSETM06-6
10	steel ball	2	XM3/16
11	outlet valve	1	DERVE011-A20
12	copper bolt	1	STH-B26
13	plug	2	XN1/4PT
14	spring	1	XF0.3-D7-D4-5L-4T
15	bolt	1	XNBHM04-06-SUS
16	O-ring	1	XBAS109
17	release valve	1	SP392-B06
18	C ring	6	XAS010
19	plug-3	1	DERVE011-A13
20	O-ring	1	XBPO18-NOK
21	back-up ring	1	XGP018
22	dust ring	1	XDDS1018
23	pump rod	1	DERVE011-A09
24	handle splint	2	DERVE011-A14
25	plug-2	1	DERVE011-A12
26	plug-1	1	DERVE011-A11
27	handle	1	DERVE011-A03
28	washer	1	DERVE011-A25
29	fixing frame	1	DERVE011-A24
30	steel ball	1	XM1/4

* repair kit